



1 2 3 4 5 6 7 8

A
B
C
D
E
F



TX75 PRO REAR



TX75S REAR

Installation Notes

- TX75PRO Receives power via CAT5. Either TX75 slave output can be used- out 1 or 2. Note that while the two jacks are labeled outputs to slave emitters, power can be inserted on either jack.
- The 8P8C jack which remains open can be used to send power and audio to a slave emitter (WIR TX75S)..

TX75 Mounting Details:

DESIGNED FOR
WILLIAMS DESIGN
CENTER

PROJECT
Powering TX75PRO
with CAT5

WILLIAMS SOUND®
HELPING PEOPLE HEAR
Williams Sound
10300 Valley View Rd.
Eden Prairie, MN 55344
1.800.328.6190

Rev	Date	Designer

SHEET
DC6

SCALE: NA