

PFM 330/330 RCH

MOTIVA™ PERSONAL FM LISTENING SYSTEM*



[GO MOBILE WITH PURE, CLEAR WIRELESS LISTENING]

The Motiva Personal FM Listening System delivers superior audio directly to the ear, enhancing sound at home, work, or school – anywhere background noise or distance from the source makes listening difficult. Motiva can be customized to meet an individual's specific hearing needs with selectable compression and adjustable frequency response.

Motiva features 16 selectable channels on the 72-76 MHz frequencies and has an operating range of up to 150 feet. A versatile 3.5mm jack allows for a variety of earphones and headphone options, and is neckloop/telecoil-equipped hearing aid compatible (not included with system).

PFM 330/330 RCH

MOTIVA™ PERSONAL FM LISTENING SYSTEM*



SYSTEMS INCLUDE

PFM 330

- Motiva™ FM Body-pack Transmitter (PFM T36)
- Motiva™ FM Receiver with Environmental Microphone (PFM R36)
- Single Mini Earbud (EAR 013)

PFM 330 RCH

- Motiva™ FM Body-pack Transmitter (PFM T36)
- Motiva™ FM Receiver with Environmental Microphone (PFM R36)
- Single Mini Earbud (EAR 013)
- (4) rechargeable AA batteries (BAT 026)
- Dual drop-in charger (CHG 3502)

APPLICATIONS

- Classrooms
- Small-group listening
- Employee training
- Consultations
- One-on-one conversations

DISCLAIMER: FCC RULES LIMIT USE OF THIS EQUIPMENT TO AUDITORY ASSISTANCE.

*NOTE: The PFM 330 and PFM 330 RCH systems are approved by the FCC for operation in U.S. Markets. The system cannot be used in all countries. Check with your government's radio regulations for 72-76 MHz operation.