

Technical Bulletin

USING A RECEIVER AS A SOUND SOURCE



WCA 092

Receiver Models: PPA R37, PPA R38, PFM R33, PFM R36, DLR 60.

The output/headphone jacks of the receivers listed above are designed to be compatible with both stereo and mono headphones. When using any of these receivers to deliver audio to a line level input of a sound system, a MONO 3.5mm plug to a mono (RCA, 3.5mm or XLR) plug should be used. If a stereo cable and plugs are used, there will be little or no signal delivered to the sound system (PA).

A William Sound cable WCA 092 (3.5mm mono to single RCA) or equivalent should be used for these applications.